



**STANDARD MODELS 5500 PD PLUS® & 5600 ACOUSTICAIR™**  
**17/46/18/85 Series Blowers**

The following list of parts, headed by the blower model number and series, are the recommended spare parts for a normal overhaul. This list includes all bearings, seals, and miscellaneous lock and screws that are not normally reusable after disassembly.

Prices quoted are Ex Works, Springfield, MO USA. Minimum order \$50.

**REPAIR KIT 27315**

<u>Item Number</u>	<u>Description</u>	<u>Part Number</u>	<u>Quantity</u>
0	Gear Lock Plate	55325	2
9	Ball Bearing	10999	2
10	Roller Bearing	29252	2
12	Lip Seal	11392	4
13	Lip Seal	11394	1
16	Timing Gear Shim	55357	1
24	Gear Key	11200	2
28	Gasket	11135	2
29	Cap Screw	90295-100	1
30	Cap Screw	92241-050	6
36	Lockwasher	5879	2
50	Roller Bearing	9903	1
51	Lab Seal	23495	4
61	Lock Plate	11057	6
65	Lock Plate	10925	2
69	Cap Screw	90295-175	1

The following part(s) are listed for reference only and are not a part of the repair kit:

8	Gear Assembly	29605*	1
39	Port Gasket	8281 (5507)	2
39	Port Gasket	8286 (5509)	2
39	Port Gasket	7862 (5511)	2
39	Port Gasket	8979 (5514)	2
39	Port Gasket	8995 (5516)	2
39	Port Gasket	8946 (5518)	2
39	Port Gasket	8946 (5520)	2

\*item 8, P/N 60193 ground gears replaced by P/N 29605 shaved gears - 5/26/05